



Explanations of the abbreviations

WA / Maintenance

M	= Manual lubrication
Z	= Prepared for connection to the central lubrication system on the tractor unit
W	= Low-maintenance with plastic top plate liner, lubrication only required on the lock jaw
LT 1P	= Low-maintenance version with plastic top plate liners and LubeTronic 1Point for automatic lock jaw lubrication
LT 5P	= LubeTronic 5Point central lubrication system
EV	= FlashTronic

ZL / Handle length

J	= Long handle
K	= Short handle

D-value calculation

T	= Permissible total weight of the tractor unit in t (including U)
R	= Permissible total weight of the semi-trailer in t
U	= Permissible imposed load on tractor in t
g	= 9,81 m/sec ²

Vehicle

ST	= Standard
MAN	= MAN
VT	= Volvo Truck
MB	= Mercedes-Benz
RT	= Renault Truck
DAF	= DAF
IV	= IVECO
SC	= Scania
DW	= Daewoo
FO	= Ford

General

oZ	= Without drawing
BH	= Mounting height
LB	= Hole pattern