



Fifth wheel coupling KKS

Spare parts: Electronic and Sensors



Spare parts: Electric and Pneumatics



Repair kits


Item	Description	Order No.	Item	Description	Order No.
31	KKS display without activation of parking break	SKE003300000	12, 13, 14, 16, 18	Kit opening cylinder	SKE003230100
31	KKS display with activation of parking break	SKE003300200	15	Kit pneumatic pipe inbetween cylinders	SKE003870100
33, 34	Kit trunk cable	SKE003310200	02, 03, 04	KKS control device without activation of parking break	SKE003180001
34	Relay	SKE003800100	02, 03, 04	KKS control device with activation of parking break	SKE003180201
01, 05, 06, 07, 08, 09, 10	Kit cable harness in fifth wheel	SKE003190000	24, 26, 27, 28, 29	Kit cylinder for connector KKS	SKE003380100
17, 18, 19, 20	Kit locking lever + magnet	SKE001360100	01, 25, 26, 27, 28, 29	Kit connector KKS (fifth wheel sided)	SKE003130100
			11, 13	Pitching angle end stop	SKE003240000

For spare parts for the fifth wheel coupling, see JSK 42

Repair instructions at www.jost-world.com

Wedge KKS

Spare parts




Repair kits

Item	Description	Order No.	Item	Description	Order No.
01-15	Kit wedge assembly	KGE 500150100	06, 07, 11	Kit wedge suspension	KGE 500230100
01, 04	Kit king pin	KGE 501201020	13, 14, 15	Connector KKS - wedge	KGE 500160100
02, 03, 04, 07	Kit wedge attachment	KGE 500100100	08, 09, 10, 15	Kit cable clamp	KGE 500130100
05, 06, 07, 11, 12, 14, 15	Kit wedge body	KGE 500070100			



Cable drum KKS

Spare parts




Repair kits

Item	Description	Order No.	Item	Description	Order No.
01-12	Kit cable drum assembly	KGE 500500100	01, 03, 04, 09	Kit spring cable drum	KGE 500690000
01, 02, 09	Kit cable drum - base tray	KGE 500510100	01, 04, 09	Kit bearing cable drum	KGE 500550000
01, 07, 08, 09, 10, 11, 12	Kit cable drum - cover plate	KGE 500610100			
06	Kit cable drum - cable	KGE 500650100			

Landing gear drive KKS + Easy Drive

Spare parts



Item	Description	Remark	Order No.	per Drive	Item	Description	Remark	Order No.	per Drive
01	Housing aluminium		JS E7001700	1	15	Bearing plate		JS E7002300	1
02	Base plate		JS E7006400	1	16	Cable		JS E7002900	1
03	Electric motor		JS E7001000	1	17	Screw M6x50		JS E7009000	4
04	Seal		JS E7001300	1	18	Screw M6x25		JS E7009300	9
05	Shaft	compl.	JS E7000200	1	19	Set of nuts		JS E7009100	1
06	Sealing ring		JS E7008500	2	20	Pressure spring		JS E7002700	2
07	Bush		JS E7008600	1	21	Tube		JS E7002600	1
08	Gearwheel		JS E7000900	1	22	Thread rod		JS E7002500	1
09	Set of lockings		JS E7008100	1	23	Housing assembly	with 01, 06 + 07	JS E7000300	1
10	Bush		JS E7008700	2	24	Bearing kit		JS E7008000	1
11	Gearwheel		JS E7000610	1	25	Support kit	with 19-22	JS E7002800	1
12	Ball bearing		JS E7008800	1	26	Electric drive assembly	with 01-18	JS E7000100	1
13	Seal		JS E7001200	1					
14	Swing bearing		JS E7008900	1					

