Maintenance

Everyone knows that regular, thorough maintenance is the most important factor in ensuring a long life span for a fifth wheel coupling. However, lubrication causes downtimes, costs

"W" version

The series JSK 37 CW/EW fifth wheel couplings and all the series JSK 42 fifth wheel couplings in version "W" are equipped with a plastic top plate liner on the mounting surface and a wearing ring with plastic insert in the locking mechanism. In conjunction with the maintenance-free rubber or pivot bearing, only one greasing point on the lock jaw needs local lubrication. All wearing parts can be replaced quickly and easily. Low-maintenance fifth wheel couplings therefore save both time and money, as well as conserving resources.



money and harms the environment. To improve the situation, there is a range of solutions that make lubrication easier or even entirely unnecessary for a period of time.



"LubeTronic 5Point" version

LubeTronic *5Point* was developed for fifth wheel couplings without top plate liners. It is a lubrication system that is integrated into the fifth wheel coupling

and ensures reliable lubrication of the fifth wheel coupling plate and lock jaw. The electronic operation of the LubeTronic minimises the consumption of lubricant and ensures optimum lubrication of the fifth wheel coupling. The grease supply is sufficient for approx. 1 year.





"LubeTronic 1Point" version

Thanks to the top plate liners, lowmaintenance fifth wheel couplings (Series W) have to be lubricated on the

lock jaw only, not on the coupling plate. The use of LubeTronic *1Point* combined with a specially-coated lock jaw also eliminates this manual procedure. After activation the LubeTronic *1Point* supplies the lock jaw with the optimum amount of grease – guaranteed for 3 years. The grease cartridge of the LubeTronic *1Point* and the lock jaw must then be replaced.



Did you know ...

... that **low-maintenance fifth wheel couplings** with plastc top plate liners (version W) can be

lubricated, but do not require it? To prevent corrosion of the trailer plate, we recommend light, basic lubrication of the trailer plate within the scope of the maintenance intervals listed in the installation and operating instructions. The locking mechanism must be lubricated. Automatic lubrication systems (such as LubeTronic *1Point*) can be installed, as the top plate liners on the low-maintenance JOST fifth wheel couplings are made not from teflon, but from polyethylene (PE).

